## Combustion and Make-Up Air submittal form

Single Family and two family dwellings

Site Address			Date
Contractor	Completed By (please print)	Signature	
	1 / 1 /		

### Section A

	Ventilation (	Quantity			
(Determine quantity by using Table R403.5.2 or Equation R403.5.2					
Square feet (Conditioned area including Basement – finished or unfinished)  Total required ventilation					
Number of bedrooms		Continuous ventilation			

Directions - Determine the total and continuous ventilation rate by either using Table R403.5.2 or equation R403.5.2 The table and equation are below.

		Tal	ole R403.5.2			
Total and Continuous V	entilation Rates	(in cfm)				
	Number of Be	Number of Bedrooms				
	1	2	3	4	5	6
Conditioned space (in	Total/	Total/	Total/	Total/	Total/	Total/
sq. ft.)	continuous	continuous	continuous	continuous	continuous	continuous
1000-1500	60/40	75/40	90/45	105/53	120/60	135/68
1501-2000	70/40	85/43	100/50	115/58	130/65	145/73
2001-2500	80/40	95/48	110/55	125/63	140/70	155/78
2501-3000	90/45	105/53	120/60	135/68	150/75	165/83
3001-3500	100/50	115/58	130/65	145/73	160/80	175/88
3501-4000	110/55	125/63	140/70	155/78	170/85	185/93
4001-4500	120/60	135/68	150/75	165/83	180/90	195/98
4501-5000	130/65	145/73	160/80	175/88	190/95	205/103
5001-5500	140/70	155/78	170/85	185/93	200/100	215/108
5501-6000	150/75	165/83	180/90	195/98	210/105	225/113

## Equation R403.5.2

 $(0.02 \times \text{square feet of conditioned space}) + [15 \times (\text{number of bedrooms} + 1)] = \text{Total ventilation rate (cfm)}$ 

**Total ventilation** – The mechanical ventilation system shall provide sufficient outdoor air to equal the total ventilation rate average, for each one-hour period according to the above table or equation. For heat recovery ventilators (HRV) and energy recovery ventilators (ERV) the average hourly ventilation capacity must be determined in consideration of any reduction of exhaust or out outdoor air intake, or both, for defrost or other equipment cycling.

**Continuous ventilation** - A minimum of 50 percent of the total ventilation rate, <u>but not less than 40 cfm</u>, shall be provided, on a continuous rate average for each one-hour period. The portion of the mechanical ventilation system intended to be continuous may have automatic cycling controls providing the average flow rate for each hour is met.

Secti	on B				
			lation Method		
			r balanced or exhaust only)		
Reco	Balanced, HRV (Heat Recovery very Ventilator) – cfm of unit i lation rating by more than 100	n low must not exceed continuous	Balanced fan systen	n	
Low		High cfm:	Continuous fan rating in c	fm (capacity must not excee	ed
			continuous ventilation rat	ing by more than 100%)	
ERV's <u>ventil</u>	. Enter the low and high <u>ation</u> rate and less than not exceed 80 cfm.) Au	od of ventilation, balanced or cfm amounts. <u>Low cfm</u> air fl 100% greater than the contin tomatic controls may allow th	ow must be equal to or nuous rate. (For instanc	greater than the requ ce, if the low cfm is 40 c	ired <u>continuous</u> cfm, the ventilation fan
		Ventilat	ion Fan Schedule		
	Description	Locatio	on	Continuous	Intermittent
	2 0001.1011.	2000.00	•••	331111111111111111111111111111111111111	
	ation fan must not exce hour.	an 100% greater than the con ed 80 cfm.) Automatic contro Vent (Describe operation and control o	ilation Controls	f a larger fan that is ор	
		(besense operation and control of	of the continuous and intern	mitterit vericiation;	
desigr ventild an ER please	n and installation complian ntion. If exhaust fans are u V or HRV is to be installed, or describe such connections mend the equipment to be	on of the ventilation system. The ce. Related trades also need ade ised for building ventilation, desc describe how it will be installed. as as detailed in the manufactures interlocked with the air handling	quate detail for placeme ribe the operation and lo If it will be connected and ' installation instructions.	nt of controls and proper cation of any controls, ind I interfaced with the air h If the installation instruc	operation of the building dicators and legends. If handling equipment, ctions require or
Secti	on E				
		N	lake-up air		
	Passive (determined from o	alculations from Table 501.4.1)			
	Powered (determined from	calculations from Table 501.4.1)			
	Interlocked with exhaust de	vice (determined from calculation fro	om Table 501.4.1)		
	Other, describe:				
		et e t			
Loca	ition of duct or system v	entilation make-up air: Detern	nined from make-up air opei	ning table	

Size and type (round, rectangular, flex or rigid)

(NR means not required)

Directions - In order to determine the makeup air, Table 501.4.1 must be filled out (see below). For most new installations, column A will be appropriate, however, if atmospherically vented appliances or solid fuel appliances are installed, use the appropriate column. For existing dwellings, see IMC 501.4.3. Please note, if the makeup air quantity is negative, no additional makeup air will be required for ventilation, if the value is positive refer to Table 501.4.2 and size the opening. Transfer the cfm, size of opening and type (round, rectangular, flex or rigid) to the last line of section D. The make-up air supply must be installed per IMC 501.4.2.

		Table 501.4.1		
		AIR QUANITY FOR EXHAL		
(Additional co	· · · · · · · · · · · · · · · · · · ·	d for combustion appliances, s		
	One or multiple power vent or direct vent appliances or no combustion appliances	One or multiple fan- assisted appliances and power vent or direct vent appliances	One atmospherically vent gas or oil appliance or one solid fuel appliance Column C	Multiple atmospherically vented gas or oil appliances or solid fuel appliances Column D
1.	Column A	Column B		
a) pressure factor (cfm/sf)	0.15	0.09	0.06	0.03
b) conditioned floor area (sf) (including				
unfinished basements)				
Estimated House Infiltration (cfm): [1a x 1b]				
Exhaust Capacity     a) continuous exhaust-only ventilation system (cfm); (not applicable to balanced ventilation systems such as HRV)				
b) clothes dryer (cfm)	135	135	135	135
c) 80% of largest exhaust rating (cfm); Kitchen hood typically (not applicable if recirculating system or if powered makeup air is electrically interlocked and match to exhaust)				
d) 80% of next largest exhaust rating (cfm); bath fan typically (not applicable if recirculating system or if powered makeup air is electrically interlocked and matched to exhaust)	Not Applicable			
Total Exhaust Capacity (cfm); [2a + 2b +2c + 2d]				
Makeup Air Quantity (cfm)     a) total exhaust capacity (from above)				
b) estimated house infiltration (from above)				
Makeup Air Quantity (cfm); [3a – 3b] (if value is negative, no makeup air is needed)				
4. For makeup Air Opening Sizing, refer to Table 501.4.2				

A. Use this column if there are other than fan-assisted or atmospherically vented gas or oil appliance or if there are no combustion appliances. (Power vent and direct vent appliances may be used.)

B. Use this column if there is one fan-assisted appliance per venting system. (Appliances other than atmospherically vented appliances may also be included.)

C. Use this column if there is one atmospherically vented (other than fan-assisted) gas or oil appliance per venting system or one solid fuel appliance.

D. Use this column if there are multiple atmospherically vented gas or oil appliances using a common vent or if there are atmospherically vented gas or oil appliances and solid fuel appliances.

# Makeup Air Opening Table for New and Existing Dwelling Table 501.4.2

	One or multiple power vent, direct vent appliances, or no combustion appliances Column A	One or multiple fan- assisted appliances and power vent or direct vent appliances Column B	One atmospherically vented gas or oil appliance or one solid fuel appliance Column C	Multiple atmospherically vented gas or oil appliances or solid fuel appliances Column D	Duct diameter
Passive opening	1-36	1-22	1-15	1-9	3
Passive opening	37 – 66	23 – 41	16 – 28	10 – 17	4
Passive opening	67 – 109	42 – 66	29 – 46	18 – 28	5
Passive opening	110 - 163	67 – 100	47 – 69	29 – 42	6
Passive opening	164 – 232	101 – 143	70 – 99	43 – 61	7
Passive opening	233 – 317	144 – 195	100 – 135	62 – 83	8
Passive opening w/motorized damper	318 – 419	196 – 258	136 – 179	84 – 110	9
Passive opening w/motorized damper	420 – 539	259 – 332	180 – 230	111 – 142	10
Passive opening w/motorized damper	540 – 679	333 – 419	231 – 290	143 – 179	11
Powered makeup air	>679	>419	>290	>179	NA

#### Notes:

- A. An equivalent length of 100 feet of round smooth metal duct is assumed. Subtract 40 feet for the exterior hood and ten feet for each 90- degree elbow to determine the remaining length of straight duct allowable.
- B. If flexible duct is used, increase the duct diameter by one inch. Flexible duct shall be stretched with minimal sags. Compressed duct shall not be accepted.
- C. Barometric dampers are prohibited in passive makeup air openings when any atmospherically vented appliance is installed.
- D. Powered makeup air shall be electrically interlocked with the largest exhaust system.

## Section F

	Combustion air	r
Not required per mechanical code (No atmospheric or	r power vented appliances)	
Passive (see IFGC Appendix E, Worksheet E-1)	Size and type	
Other, describe:	'	-

Explanation - If no atmospheric or power vented appliances are installed, check the appropriate box, not required. If a power vented or atmospherically vented appliance installed, use IFGC Appendix E, Worksheet E-1 (see below). Please enter size and type. Combustion air vent supplies must communicate with the appliance or appliances that require the combustion air.

Section F calculations follow on the next 2 pages.

Directions - The Minnesota Fuel Gas Code method to calculate to size of a required combustion air opening, is called the Known Air Infiltration Rate Method. For new construction, 4b of step 4 is required to be filled out.

IFGC Appendix E, Worksheet E-1 Residential Combustion Air Calculation Method	
(for Furnace, Boiler, and/or Water Heater in the Same Space)	
Step 1: Complete vented combustion appliance information. Furnace/Boiler:	
Draft Hood Fan AssistedDirect Vent Input:Btu/hr or Power Vent	
Water Heater:	
Draft Hood Fan Assisted Direct Vent Input:Btu/hr or Power Vent	
Step 2: Calculate the volume of the Combustion Appliance Space (CAS) containing combustion appliances.	
The CAS includes all spaces connected to one another by code compliant openings.  L x W x H  L W  H  CAS volume:	ft³
Step 3: Determine Air Changes per Hour (ACH)1	
Default ACH values have been incorporated into Table E-1 for use with Method <b>4b</b> (KAIR Method).	
If the year of construction or ACH is not known, use method 4a (Standard Method).	
Step 4: Determine Required Volume for Combustion Air. (DO NOT COUNT DIRECT VENT APPLIANCES)	
4a. Standard Method	
Total Btu/hr input of all combustion appliances Input: Btu/hr	
Use Standard Method column in Table E-1 to find Total Required TRV:ft <sup>3</sup>	
Volume (TRV)	
If CAS Volume (from Step 2) <i>is greater than</i> TRV then no outdoor openings are needed.	
If CAS Volume (from Step 2) is less than TRV then go to STEP 5.	
4b. Known Air Infiltration Rate (KAIR) Method (DO NOT COUNT DIRECT VENT APPLIANCES)	
Total Btu/hr input of all <b>fan-assisted and power vent</b> appliances Input: Btu/hr	
Use Fan-Assisted Appliances column in Table E-1 to find RVFA:ft³ Required Volume Fan Assisted (RVFA)	
Total Btu/hr input of all <b>Natural draft</b> appliances Input: Btu/hr	
Use Natural draft Appliances column in Table E-1 to find RVNFA:ft³  Required Volume Natural draft appliances (RVNDA)	
Total Required Volume (TRV) = RVFA + RVNDA	.3
If CAS Volume (from Step 2) is greater than TRV then no outdoor openings are needed.	
If CAS Volume (from Step 2) <i>is less than</i> TRV then go to <b>STEP 5. Step 5:</b> Calculate the ratio of available interior volume to the total required volume.	
Ratio = CAS Volume (from Step 2) <i>divided by</i> TRV (from Step 4a or Step 4b)	
Ratio = / =	
Step 6: Calculate Reduction Factor (RF).	
RF = 1 minus Ratio RF = 1 - =	
Step 7: Calculate single outdoor opening as if all combustion air is from outside.	
Total Btu/hr input of all Combustion Appliances in the same CAS	
(Exel Filling)	
Combustion Air Opening Area (CAOA):	
Total Btu/hr <i>divided by</i> 3000 Btu/hr per in <sup>2</sup> CAOA = /3000 Btu/hr per in <sup>2</sup> in <sup>2</sup>	
Step 8: Calculate Minimum CAOA.	
Minimum CAOA = CAOA <i>multiplied by</i> RF Minimum CAOA = x = in <sup>2</sup>	
Step 9: Calculate Combustion Air Opening Diameter (CAOD)	
CAOD = 1.13 <i>multiplied by the square root of</i> Minimum CAOA CAOD = 1.13 V Minimum CAOA =in. diameter go up one inch in size if using flex duct	
1 If desired, ACH can be determined using ASHRAE calculation or blower door test. Follow procedures in Section	
1 1351/4	

Input Rating	Standard Method	air (Required Interior Volume Based on Input Rating of Appliance)  Known Air Infiltration Rate (KAIR) Method (cu ft)				
(Btu/hr)		Fan Assisted or Power Vent Natural Draft			· 	
		1994 to present	Pre-1994	1994 to present	Pre-1994	
5,000	250	375	188	525	263	
10,000	500	750	375	1,050	525	
15,000	750	1,125	563	1,575	788	
20,000	1,000	1,500	750	2,100	1,050	
25,000	1,250	1,875	938	2,625	1,313	
30,000	1,500	2,250	1,125	3,150	1,575	
35,000	1,750	2,625	1,313	3,675	1,838	
40,000	2,000	3,000	1,500	4,200	2,100	
45,000	2,250	3,375	1,688	4,725	2,363	
50,000						
55,000	2,500 2,750	3,750 4,125	1,675	5,250	2,625	
· ·			2,063	5,775	2,888	
60,000	3,000	4,500	2,250	6,300	3,150	
65,000	3,250	4,875	2,438	6,825	3,413	
70,000	3,500	5,250	2,625	7,350	3,675	
75,000	3,750	5,625	2,813	7,875	3,938	
80,000	4,000	6,000	3,000	8,400	4,200	
85,000	4,250	6,375	3,188	8,925	4,463	
90,000	4,500	6,750	3,375	9,450	4,725	
95,000	4,750	7,125	3,563	9,975	4,988	
100,000	5,000	7,500	3,750	10,500	5,250	
105,000	5,250	7,875	3,938	11,025	5,513	
110,000	5,500	8,250	4,125	11,550	5,775	
115,000	5,750	8.625	4,313	12,075	6,038	
120,000	6,000	9,000	4,500	12,600	6,300	
125,000	6,250	9,375	4,688	13,125	6,563	
130,000	6,500	9,750	4,875	13,650	6,825	
135,000	6,750	10,125	5,063	14,175	7,088	
140,000	7,000	10,500	5,250	14,700	7,350	
145,000	7,250	10,875	5,438	15,225	7,613	
150,000	7,500	11,250	5,625	15,750	7,875	
155,000	7,750	11,625	5,813	16,275	8,138	
160,000	8,000	12,000	6,000	16,800	8,400	
165,000	8,250	12,375	6,188	17,325	8,663	
170,000	8,500	12,750	6,375	17,850	8,925	
175,000	8,750	13,125	6,563	18,375	9,188	
180,000	9,000	13,500	6,750	18,900	9,450	
185,000	9,250	13,875	6,938	19,425	9,713	
190,000	9,500	14,250	7,125	19,950	9,975	
195,000	9,750	14,625	7,313	20,475	10,238	
200,000	10,000	15,000	7,500	21,000	10,500	
205,000	10,250	15,375	7,688	21,525	10,783	
210,000	10,500	15,750	7,875	22,050	11,025	
215,000	10,750	16,125	8,063	22,575	11,288	
220,000	11,000	16,500	8,250	23,100	11,550	
225,000	11,250	16,875	8,438	23,625	11,813	
230,000	11,500	17,250	8,625	24,150	12,075	

The 1994 date refers to dwellings constructed under the 1994 Minnesota Energy Code. The default KAIR used in this section of the table is 0.20 ACH.

<sup>2.</sup> This section of the table is to be used for dwellings constructed prior to 1994. The default KAIR used in this section of the table is 0.40 ACH.